





Conectar al "KE" Y "K" del GT-1D



GT-1D

PANEL ITZUMI



NOTA: CORTAR PUENTE  PARA HABILITAR PANICO